

## Enter setup

## **Control character conversion**



GS



<GS>



(GS)



'GS'



`GS`



GS\_124



End character conversion on



End character conversion off



## Output as is



Exit setup

For example: add 'GS' and enter characters to the barcode, and scan the following barcode from top to bottom to set it up successfully  $\circ$ 



Enter setup



GS



'GS'



## End character conversion on



Exit setup

Option 3 (Send a special character, ALT + XXX (ASCII), in this case, the GS character is ALT + 029. (This is how the scanner works in VCOM, but not in the USB keyboard)

This problem can be solved by setting the following barcode



Enter setup



Output Characters ALT+Numeric keys



Exit setup