



Enter Setting

1. Different Type of Bar Code Settings

1.1 Codabar



On



Off



Check Off



Check on but Digit Transmission Off



Check on and Digit Transmission On



Save and exit



Enter Setting

1.2 Code 2 of 5 Interleaved



On



Off



Check Off



Check on but Digit Transmission Off



Check on and Digit Transmission On



Save and exit



Enter Setting

1.3 Plessey Code



On



Off



Check Off



Check on but Digit Transmission Off



Check on and Digit Transmission On



Save and exit



Enter Setting

1.4 Code 2 of 5 China Post



On



Off



Check Off



Check on but Digit Transmission Off



Check on and Digit Transmission On



Save and exit



Enter Setting

1.5 Code 2 of 5 Matrix



On



Off



Check Off



Check on but Digit Transmission Off



Check on and Digit Transmission On



Save and exit



Enter Setting

1.6 Code 2 of 5 Industrial



On



Off



Check Off



Check on but Digit Transmission Off



Check on and Digit Transmission On



Save and exit



Enter Setting

1.7 Code 2 of 5 IATA



On



Off



Check Off



Check on but Digit Transmission Off



Check on and Digit Transmission On



Save and exit



Enter Setting

1.8 ITF-14



On



Off



Check Digit Transmission Off



Check Digit Transmission On

1.9 DP-12



On



Off



Save and exit



Enter Setting



Check Digit Transmission Off



Check Digit Transmission On

1.10 DP-14



On



Off



Check Digit Transmission Off



Check Digit Transmission On



Save and exit



Enter Setting

1.11 Code 128



On



Off

1.12 GS1-128



On



Off

1.13 AIM-128



On



Save and exit



Enter Setting



Off

1.14 ISBT-128



On



Off

1.15 MSI



On



Off



Save and exit



Enter Setting



One check, no output



One check, output



Two-digit check (MOD10,MOD10),no output



Two-digit check (MOD10,MOD10), output



Two-digit check (MOD10,MOD11),no output



Two-digit check (MOD10,MOD11), output



Check Off



Save and exit



Enter Setting

1.16 Code 11



On



Off



Check Digit Transmission Off



Check Digit Transmission On

1.17 Code 39



On



Off



Save and exit



Enter Setting



Enable Start Character



Disable Start Character



Enable Full ASCII Characters



Disable Full ASCII Characters



Check Off



Check on but Digit Transmission Off



Check on but Digit Transmission On



Save and exit



1.18 Code 32



On



Off

1.19 Code 93



On



Off





Enter Setting

1.20 EAN-8



On



Off



Check Off



Check On



Convert EAN-8 to EAN-13 On



Convert EAN-8 to EAN-13 Off



Save and exit



Enter Setting

1.21 EAN-13



On



Off



Check Off



Check On



Convert EAN-13 to ISBN/ISSN On



Convert EAN-13 to ISBN/ISSN Off



Save and exit



Enter Setting

1.22 UPC-E



On



Off



Check Off



Check On



Convert UPC-E to UPC-A On



Convert UPC-E to UPC-A Off



Save and exit



Enter Setting

1.23 UPC-A



On



Off



Check Off



Check On

1.24 RSS-14



On



Off



Save and exit



Enter Setting

1.25 RSS-Limited



On



Off

1.26 PDF-417



On



Off

1.27 QR Code



On





Enter Setting



Off



Mirror flip On



Mirror flip Off

1.28 Data Matrix



On



Off



读取长方形版本



Save and exit



Enter Setting



不读取长方形版本



可读取反相符号



不读取反相符号



可读取镜像符号



不读取镜像符号

1.29 Aztec Code



On



Off



Save and exit



Enter Setting

2. Reading Mode



Level Trigger Mode



Continuous Scan



Auto-Sensor Mode

3. Image flip



Normal



Flip up and down and left and right at the same time



Save and exit



Enter Setting

Only Flip up and down



Only Flip left and right

4. Caps Lock



No Conversion



To Uppercase



To Lowercase



Conversion



Save and exit



Enter Setting

5. Prefix and Suffix



Enter prefix setting (1~16 bytes)



Enter suffix setting (1~16 bytes)



Enter end symbol setting(1~8 bytes)



No Suffix



Add Suffix-CR



Add Suffix-CR+LF



Add Suffix-TAB



Save and exit



Enter Setting

Parameters Table

Scan the parameter code according to the table in Appendix I



0



1



2



3



4



5



6



7



8



9



Save Settings



Give up setting





Appendix I : ASCII Character Comparison Table

Scanned number	Keyboard value	Scanned number	Keyboard value	Scanned number	Keyboard value
1000	Null	1043	+	1086	V
1001	Keypad Enter	1044	,	1087	W
1002	Caps lock	1045	-	1088	X
1003	Right Arrow	1046	.	1089	Y
1004	Up Arrow	1047	/	1090	Z
1005	Null	1048	0	1091	[
1006	Null	1049	1	1092	\
1007	Enter	1050	2	1093]
1008	Left Arrow	1051	3	1094	^
1009	Horizontal Tab	1052	4	1095	_
1010	Down Arrow	1053	5	1096	'
1011	Vertical Tab	1054	6	1097	a
1012	Backspace	1055	7	1098	b
1013	Enter	1056	8	1099	c
1014	Insert	1057	9	1100	d
1015	Esc	1058	:	1101	e
1016	F11	1059	;	1102	f
1017	Home	1060	<	1103	g
1018	Print Screen	1061	=	1104	h
1019	Delete	1062	>	1105	i
1020	tab+shift	1063	?	1106	j
1021	F12	1064	@	1107	k
1022	F1	1065	A	1108	l
1023	F2	1066	B	1109	m
1024	F3	1067	C	1110	n
1025	F4	1068	D	1111	o
1026	F5	1069	E	1112	p
1027	F6	1070	F	1113	q
1028	F7	1071	G	1114	r
1029	F8	1072	H	1115	s
1030	F9	1073	I	1116	t
1031	F10	1074	J	1117	u





Enter Setting

1032	Space	1075	K	1118	v
1033	!	1076	L	1119	w
1034	"	1077	M	1120	x
1035	#	1078	N	1121	y
1036	\$	1079	O	1122	z
1037	%	1080	P	1123	{
1038	&	1081	Q	1124	
1039	'	1082	R	1125	}
1040	(1083	S	1126	~
1041)	1084	T		
1042	*	1085	U		



Save and exit